

German Schmear Applications

*Interior or Exterior rated

Products: AquaStone®, SetCoat® White



Mortar and Brick – heavy trowel

- step 1. Mix AquaStone® and White SetCoat® in a 50/50 ratio.
- step 2. Stipple on with a pounce brush covering about 50% of the area.
- step 3. Knock down with a trowel to create the effect leaving open areas.

Tips: Mix can be thinned with water up to 10% for translucency. Add more in mortar areas with a chip brush.



Mortar and Brick wash – light coverage

- step 1. Mix AquaStone® and White SetCoat® in a 50/50 ratio.
- step 2. Add 20% water by volume. Mix well.
- step 3. Apply by brushing on the mixture with a pounce brush, brushing sideways until desired look is achieved. Wipe back areas with terry cloth, if desired.
- step 4. Add more in mortar areas with a chip brush.



Mortar and Brick wash – full coverage

- step 1. Mix AquaStone® and White SetCoat® in a 50/50 ratio.
- step 2. Apply by brushing on the mixture over entire surface with a pounce brush, brushing sideways until desired look is achieved.
- step 3. When dry, apply Step 2 again for more coverage.

