

## ShimmerCoat™ Basic Application

Products: ShimmerCoat™

Tools: 1/4" Nap Roller, Pounce Brush. Chip Brushes, Tape

Step 1. Roll ShimmerCoat™ over any existing paint/finish to add a shimmering effect. Roll on evenly and generously.

Step 2. Soften the rolled ShimmerCoat™ with a pounce brush to bring out the shimmer when dry. Pounce over surface continually overlapping as you go. Avoid leaving (pounce brush) circle marks.

Step 3. Allow to dry to reveal the shimmering results.





